

Controlling the NMM Multimedia-Box

March, 30th 2004

Copyright (c) 2002-2005
NMM work group,
Computer Graphics Lab,
Saarland University, Germany,
<http://www.networkmultimedia.org>

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license can be found in the file COPYING.FDL.

Key assignment for controlling the NMM Multimedia-Box.

1. Key assignment

Table 1. General key assignment

Up, Down, Left, Right	Navigation
Enter	Select
p	Pause
f	Fast forward
r	Rewind
l	Stop playback
o	On-screen menu on/off
q	Return to previous state without stopping current state
ESC	Destroy current state and return to previous state
Page Up	Increase volume
Page Down	Decrease volume

F1	Red color key
F2	Green color key
F3	Yellow color key
F4	Blue color key
F5	Make screenshot
F12	Exit mmbox

Table 2. Menus

Up, Down, Left, Right	Navigation
Enter	Enter sub-menu

Table 3. Live TV

Up, Down	Change channel
p	Pause live TV, start time-shifting
p (again)	Continue live TV
f	Fast forward in time-shifting buffer
r	Rewind in time-shifting buffer
Enter	Continue at current position in time-shifting buffer
l	Stop time-shifting
F1	Record current show (only with EPG-information available)
F2	Show/Hide details for current program (only with EPG-information available)
F3	Display/Close the channels-list (with currently running shows, if info is available)
F4	Display/Close the channels-list (with following running shows, if info is available)
o	On-screen menu on/off

Table 4. TV Timer

Left, Right	Change window
-------------	---------------

Up, Down	Scrolling
Enter	New Timer, Change Timer or finish programming of timer
0..9	Change Timer-Settings
F1	Delete Timer
F2	Change Timer
F3	Playback a recorded Timer
F3	Connect to a recording Timer
F3	Display Timers conflicting with the selected
F4	Program a new Timer
Editing a Timer	
F1	Leave editing timer without changes
F2	Leave editing timer with changes
F3	Change Period of Timer

Table 5. TV Guide

Left, Right	Change window
Up, Down	Move line up/down in current window
F1	Program a timer for the selected show
F2	Switch to selected channel

Table 6. TV Guide-Search

Left, Right	Change window
Up, Down	Move line up/down in current window
0..9	Text-input
F1	Program a timer (in Result-Windows)
F2	Mark selected line
F3	Save current filter-settings as bookmark
F4	Start search
F4	Switch to the channels the selected show is running on (in Result-Windows)

Table 7. Play DVD

Up, Down, Left, Right	Navigation, within DVD menus
Enter	Select within DVD menus
p	Pause playback
p (again)	Continue playback
Left, Right	Go to last/next chapter

Table 8. Grab DVD

Up, Down, Left, Right	Navigation within setup menu
Enter	Start grabbing

Table 9. Play CD

Up, Down	Navigation in track list
Enter	Select and play track
p	Pause playback
p (again)	Continue playback
f	Fast forward
r	Rewind
l	Stop playback

Table 10. Grab CD

no interaction

Table 11. MP3

Up, Down	Navigation in track list and directory structure
Enter	Select and play track
p	Pause playback

p (again)	Continue playback
f	Fast forward
r	Rewind
Right	Fast forward
Left	Rewind
l	Stop playback

Table 12. Playlist

Left, Right	Change between 'playlist window' (top window), 'selection window' (left window), 'file window' (right window)
Up, Down	Move line up/down in current window
Enter	Select and play track in file window or playlist window
Enter	Open source in 'selection window'
F2	Add selected entry (file/directory) in 'file window' to 'playlist window'
F1	Delete file/directory in 'file window'
F2	Select entry in 'playlist window', then ...
Up, Down	Move selected entry in 'playlist window' up/down
F2	Drop selected entry at new position in 'playlist window'
F1	Delete entry in 'playlist window'
p	Pause playback
p (again)	Continue playback
f	Fast forward
r	Rewind
l	Stop playback
o	On-screen menu on/off during video playback

Table 13. Transcode

Jobmanager Window	
Left, Right	Change between 'Transcoding-Task' window and 'Transcodingjobs' window

Up, Down	Move line up/down in current window
F1	Delete Task 'Transcoding-Tasks window'
F1	Delete Job 'Transcoding-Jobs window'
F1	Leave spymode
F2	Create new Task in 'Transcoding-Task window'
F3	Pause Job in 'Transcoding-Job window'
F4	Spymode for videojobs (preview current input/output video stream)
Transcode-Config Window	
Left, Right	Change between windows
Left, Right	Change options in 'edit options' mode
Up, Down	Move line up/down in current window
F2	Start selected transcoding job
F4	Enter 'edit option' mode
Playlist Window	
Left, Right	Change between 'playlist window' (top window), 'selection window' (left window), 'file window' (right window)
Up, Down	Move line up/down in current window
Enter / F4	Select and transcode track in file window or playlist window
Enter	Open source in 'selection window'
F2	Add selected entry (file/directory) in 'file window' to 'playlist window'
F1	Delete file/directory in 'file window'
F2	Select entry in 'playlist window', then ...
F2	Drop selected entry at new position in 'playlist window'
F1	Delete entry in 'playlist window'

Table 14. Tasklist

Up, Down	Move line up/down in list of states
Enter	Go to selected state
F1	Destroy selected state
F2	Switch to selected state

Table 15. Config

Up, Down	Move line up/down in list of options
Left, Right	Change value for selected option
Enter	Save all values